

1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1





FIG. 1

FIG. 2



250 251 252 253 254 255 256 257 258 259 260 261 262 263 264




FIG. 3




FIG. 4

Module Cross-Reference Database (mxrDoc)




FIG. 5

Component Cross-Reference Database (cxrDoc)




FIG. 6

Include Component(s)

[? X]

The following components will be included:

target debugging
shell banner
target shell

NOTE: The following components are required by the components to the left and will also be included:

floating point show routine
C++ symbol demangler
target loader

Image size change (bytes)

text	data	bss	total
83872	12908	916	97696

Size of included components (bytes)

text	data	bss	total
331608	21376	25464	368448

OK

Cancel

Help

FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11





FIG. 12

FIG. 13a






FIG. 13b





FIG. 14

FIG. 15






FIG. 16a




FIG. 16b




FIG. 16c




FIG. 17




FIG. 18